

1000 m2

4 liter Sun Foam Complex
8 liter BioClean Complex
4-8 liter Cid Complex

I. Prudent Basic Program: Hygiene

Sun Foam Complex

Recommended concentration: 1%

Time of impact: 10 minutes

BioClean Complex

Recommended concentration: 2%

Time of impact: 5 minutes

Cid Complex

Recommended concentration: 1-2%

Time of impact: 30 minutes

Hygiene control test: ATP test

Cleaning and disinfection program

The room must be brought to a sweeping clean state, then soak with a tube a day before.

1. Preparation phase 1 (degreasing)	
Product	Implementation
Sun Foam Complex	Mode of application: with a foam generator Recommended concentration: 1% Time of impact: 10 minutes

2. Rinse phase	
	Implementation
Washing, rinsing with high-pressure equipment	Keep the head as far as possible from the surface, thus avoiding the backlash of the condensation of dirt that may have remained there. Allow a short drying time to allow the next chemical to adhere to the surface more easily.

3. Pretreatment phase (descaling)	
Product	Implementation
BioClean Complex	Mode of application: with a high-pressure equipment Recommended concentration: 2% Time of impact: 5 minutes

4. Rinse phase	
	Implementation
Washing, rinsing with high-pressure equipment	Keep the head as far as possible from the surface, thus avoiding the backlash of the condensation of dirt that may have remained there. Allow a short drying time to allow the next chemical to adhere to the surface more easily.

5. Disinfection phase	
Product	Implementation
Cid Complex	Mode of application: with a fogging equipment (in a dry room) Recommended concentration: 1-2% Time of impact: 30 minutes